











Wireless Optical Heat Detector
Installation Guide

Part No. 10-013





1. Enter Engineering Menu
2. Scroll to Add new device
3. Enter menu



1. Select the device type 'OPT'
2. Choose the logical address
3. Accept the new device

